Stepped Dim Microwave Movement Sensor

This product is fitted with a stepped dim microwave movement sensor. Please see below detailed operating instructions.

MULTI-FUNCTION SENSOR SPECIFICATIONS:


DC Input Voltage	12±1V DC
Rated Voltage	12±0.6V DC
Stand-by Power	<0.3W
Efficiency	>80%
Operating Frequency	5.8 GHz ±75 MHz
Transmitting Power	0.2mW Max.
Hold Time	5s / 90s / 3min / 10min
Stand-by DIM Level	10% / 30%
Stand-by Period	0s / 10s /10min / +∞
Detection Area	100% / 50%
Daylight Sensor	10Lux / Disable
Detecting Radius	12m (mounting height 3m)
Mounting Height	6m Max
Detecting Angle	30~150°
Operating Temperature	-20°C+60°C



Detection area is effected on volume of motion object and motion speed. The detection area is tested by a 165cm height person and walking speed is 0.3m/s.

FUNCTION:

threshold)





daytime even when movement ambient lux level, the light is the light dims to stand-by is detected. (Ambient lux triggered on 100% by the level is above preset daylight detector.

With movement and insufficient If there is no more movement, dimming level after hold-time.


3

Ī The light turns off automatically after stand-by time.

 \bigcirc

H-JIN

DIP SWITCH SETTING:



Care and Safety

We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish. For your safety, always switch off the power supply before cleaning.

For further information, please visit https://www.lighting-info.co.uk/95543

V5 20/01/2024 UK Manufacturer: BH17 7BY EU Manufacturer: Brilliant AG, Brilliantstrasse 1, D-27442 Gnarrenburg



Instruction manual

HeroPro CCT Step Dimming

95543





Warning

This light fitting is double insulated and does not require connection to an earth circuit.

Please read these instructions carefully before commencing any work. This unit must be fitted by a competent and gualified electrician.

Install in accordance with the IEE Wiring regulations and current Building Regulations.

Check the pack and make sure you have all the parts listed.


To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

If replacing an existing fitting, make a careful note of the connections.

This light fitting should be connected to a fused circuit.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Technical data



Layout

Plan the desired layout of these fittings carefully, ensuring the cables will reach the distances between each light fitting.

Avoid locating any cables in positions that would cause a hazard. Position cables and junction boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.

The mains supply cable must have a minimum cross section area of 1.0mm².

Cables must be protected using suitable conduit or plastic trunking.

The products can be wall or ceiling mounted. If wall mounting ensure that the power supply is at the bottom.

• Replace fuse or circuit breaker and switch on. Your light is now ready for use.

Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, carefully note the position of each set of wires.

Note that the switch is turned off before installation.

The ceiling surface must be flat and smooth to ensure a good fit.

Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.

- Twist and remove the lamp cover from the product, keep safe for refitting later. Pull the cable through the cable entry hole and seal to maintain the IP rating
- Turn the clip to loose the LED tray in the rear casing.
- Refit the LED tray back into the rear casing and lock the clip. • Using the rear casing as a template mark the position to drill out the fixing holes. Take care to avoid damaging any concealed wiring and pipes. Twist the lamp cover back onto the product and lock in place.
- Fix the rear casing into the position using the installation plugs and screws.




The wattage is changeable between 18/14/9W using the wattage switch on the driver before installation.

18W 14W 9W 6000K 4000K 3000K 6KI4KI3K

The colour is changeable between 3000/4000/6000K using the CCT switch on the driver before installation.

and wire as detailed Wiring Diagram.

Choose your preferred wattage and colour before installing by wattage switch or CCT switch on the driver. Note: Befeore you change the wattage or colour, please turn off the power switch for safety.





Bezels

The following individual casings are available for purchase separately. 95545 : Chrome plain 95548 : Black plain 95551 : Anthracite grey plain 95546 : White eyelid 95549 : Black eyelid 95552 : Anthracite grey eyelid 95547 : White grill 95550 : Black grill 95553 : Anthracite grey grill

Wiring

Having correctly identified the wiring from your existing light fitting, pull the mains wire through the hole and connect to the quick fit connection block in the following way. No tools are necessary.





Check that...

You have correctly identified the wires. The connections are tight. No loose strands have been left out of the connection block.